

TABLE OF CONTENTS

1090, 1170 AND 1175 TRACTORS

SERIES	SECTION	DESCRIPTION	FORM NUMBER
10		GENERAL	
	11	General Specifications - 1090 Tractors	9-79731
	11	General Specifications 1170 & 1175 Tractors	9-79741
	13	Lubrication - 1090 Tractors	9-79671
	13	Lubrication - 1170 & 1175 Tractors	9-79681
	1021	Detailed Specifications - 451BD Engine - 1090 Tractors	9-77075
	1021	Detailed Specifications - 451BDT Engine - 1170 & 1175 Tractors	9-77265
20		ENGINES	
	2001	Engine Diagnosis	9-76365
	2002	Engine Tune-Up	9-76379
	2015	Cylinder Head, Valve Train and Camshaft	9-76166
	2025	Cylinder Block, Sleeves, Pistons and Rods	9-76176
	2035	Crankshaft, Main Bearings, Flywheel and OilSeals	9-76187
	2046	Lubrication System, Oil Pump and Oil Flow Diagrams	9-76805
	2055	Cooling System	9-76337
	2065	Turbocharger - T04B	9-78026
	2165	Turbocharger - T04	9-78435
	2565	Turbocharger Failure Analysis	9-78235
	2290	Reconditioning Engine Cylinder Block	8-21170
30		FUEL SYSTEM	
	3010	Fuel System	9-75297
	3012	Robert Bosch Fuel Injection Pumps	9-74937
	3013	Roosa Master Fuel Injectors	9-74959
	3015	Repairing Polyethylene Fuel Tanks	9-76305
	3016	Repairing Cast Nylon Fuel Tanks	9-79753
40		HYDRAULICS	
	4010	Hydraulic Oil Filters	9-79113
	4011	Dual Hydraulic Pump	9-79083
	4014	Dual Remote Valve	9-79033
	44	Flow Divider - PTO Control Valve	9-79192
	45	Draft-O-Matic System	9-79123
	4019	Break-Away Couplings and Portable Cylinders	9-74197
50		STEERING	
	5010	Steering Column and Hand Pump (Used Prior to Tractor SN8693001)	9-78853
	5010	Steering Column and Pump-Valve (Starting W/Tractor SN8693001)	9-74269
	53	Steering Control Valve	9-78832
	54	Hydrostatic Steering Actuator	9-78782
	5015	Steering Axle (Starting W/Tractor SN8736747)	9-78773
	55	Steering Axle (Used Prior to Tractor SN8736747)	9-79582
60		POWER TRAIN	
	6001	Trouble Shooting RPS-34 Power Shift	9-76037
	62	Power Shift Transmission - 1090 Tractors	9-79074
	63	Planetary Final Drive - Transmission - 1170 & 1175 Tractors	9-79661
	63a	Planetaries	9-75926
	64	Final Drive and Transmission - 1090 Tractors	9-78963
	6045	Hydraulic PTO	9-79173
	66	14" & 15" Traction Clutches and Linkage	9-78972
70		BRAKES	
	73	Power Assist Unit and Pedals	9-78923
	7012	Power Assist Brake Valve W/Adjustable Relief Valve	9-45871
	7012	Differential and Parking Brakes	9-78903
	74	Caliper Disc Brakes and Parking Brake	9-79622

Reprinted

80	ELECTRICAL	
81	Wiring Diagram - 1090 & 1170 Tractors	9-79721
8010	Wiring Diagram - 1175 Tractors (Prior to SN8753831)	9-77106
8010	Wiring Diagram - 1175 Tractors (Starting W/SN8753831)	9-79995
8011	Wiring Diagram - Tractor Cabs Prior to SN7814176	9-77125
8011	Wiring Diagram - Tractor Cabs Starting W/SN7814176	9-77698
8012	Cranking Motors	9-75366
8013	Battery Servicing and Testing	9-75377
8014	Prestolite Alternator System	9-75399
8114	Delco-Remy Alternator System	9-78976
90	ACCESSORIES	
92a	Cab Sealing and Recirculation	9-75915
9005	Trouble Shooting - Air Conditioning System	9-78895
9015	Gauging and Testing - Air Conditioning System	9-78995
9025	Compressor Isolation, Removal, Installation and Evacuation System Discharging, Evacuation and Charging	9-79015
9035	Servicing Air Conditioning Components	9-78705
9050	Seat Adjustments (Swivel and Non Swivel)	9-79755
100	HOW IT WORKS	
101	Hydraulic Testing - Steering & Brakes	9-79821
111	Hydraulic Testing - Power Shift, Remotes & PTO	9-79832
141	Hydraulic System	9-79701
141	Dual Pump - Flow Divider Valve	9-79182
141	Dual Remote Hydraulic System	9-79022
141	Draft-O-Matic System	9-79042
151	Power Steering - Brakes	9-79782
161	Hydraulic PTO	9-79242
161	Power Shift Transmission	9-79232
19010	Air Conditioning	9-78615